

DIGITAL THERMOMETER

WT-1

Parameters

- ◆ Temperature range: $-50^{\circ}\text{C} \sim +300^{\circ}\text{C}$ ($-58^{\circ}\text{F} \sim +572^{\circ}\text{F}$)
- ◆ Distinguishing rate: 0.1°C
- ◆ Accuracy: $(-20^{\circ}\text{C} \sim 80^{\circ}\text{C}) \pm 1^{\circ}\text{C}$
- ◆ Power voltage: DC 1.5V

Functions

- ◆ Memory of the last measuring
- ◆ Measuring and display low voltage
- ◆ Saving power: auto-off after 15 minutes of no-operation
- ◆ Sensor fault display
- ◆ Switch between $^{\circ}\text{C}$ and $^{\circ}\text{F}$

Operation description

- ◆ [ON/OFF]: Press the key to turn on/off the thermometer.
When turn on it displays the last measuring temperature for 1.5 second then enters into measuring mode. Auto-off after 15 minutes of no-operation.
- ◆ [$^{\circ}\text{C}/^{\circ}\text{F}$]: In the mode of temperature display press the key to switch between $^{\circ}\text{C}$ and $^{\circ}\text{F}$.
- ◆ Measuring and display low voltage: when voltage lower than 1.3V LCD displays "LOW".
- ◆ Display E00 when sensor open circuit or lower than measuring range; Display E11 when sensor short circuit or higher than measuring range.