## **Operating Instruction (TPM-10A)**

## Features

- LCD display
- Insert design
- Simple appearance
- Two button batteries use for longer time
- Especially applied in refrigerator, chiller, deepfreeze etc.

## Technical parameter

- Measurement range: -50°C ~+70°C
- Using environment: Temperature: -10°C~+50°C

Humidity:5% $\sim$ 80%

Accurancy: ±1°CDistinguish: 1°C

Power: two button battery ( LR44,1.5V)

## Instruction

- Open the battery cover and put in two LR44 batteries correctly, be assure not to turn over.
- Display when put in the batteries.Pls take out the batteries when not using for long time (Notes: First use pls take out the thin insulative slice)
- LCD display H<sup>°</sup>C when temperature is higher than 70 °C;
  LCD display L<sup>°</sup>C when temperature is lower than -50 °C.
- Insert size: 46 x 26.6mm